

Seznam materiala za programsko definirani radijski sprejemnik
različica 7 MHz (40m)

Oznaka elementov	Vrednost	Ohišje	Število
UPORI			
R1, R7	10k	1206	2
R2	15k	1206	1
R3	220R	1206	1
R4, R8, R13	1k	1206	3
R5	470R	1206	1
R6, R11, R12, R14, R15	10R	1206	5
R9, R10 (4,99k oz. 2x10k vzporedno)	10k	1206	4
R16	1k	klasičen	1
KONDENZATORJI			
C1, C18	10uF (TANTAL)	SIZE D	2
C2, C7, C8, C9, C10, C11, C14, C17, C19, C20, C21	100nF	C1206	11
C4, C23	100pF	C1206	2
C6	22pF	C1206	1
C12, C13	220pF	C1206	2
C15, C16	47nF	C1206	2
C22	1,5nF	C1206	1
OSTALO			
Quartz X1	28,224 MHz		1
IC1, IC2	74H74	SOIC	2
IC3	SN74CBT3257D	SOIC	1
IC4	OPA2228	SOIC	1
T1	2N3904	TO-92A	1
T2	2N3906	TO-92A	1
D1	1N4007	D0-41	1
L1, L2	Jedra T25-2 ali T30-2		2
JP1, P5	Letvica za Jumper		2
3,5 mm Stereo Audio Jack			1
BNC	BNC priključek (montirano na ohišje)		1